



How To Measure For Glass Inserts

In order for us to get the exact measurements we need please follow the directions below and put them on our Measurement Sheet

Woelky's Glass Studio
Telephone: 714.287.6447
Fax: 1-520-582-9443
Email: woelky4@verizon.net
www.wgsartglass.com

Tight Size Measurements - (See photos) This measurement will tell us the maximum area we have to work with. From the **backside of the cabinet frame** carefully measure the maximum area that the glass will fit into. Carefully measure the maximum width and the maximum height of the area that the glass insert will fit into.



Light Size Measurements - (See photos) This measurement will give us the size of the lip or rabbet so that we know how much of the insert goes underneath the wood molding. On the **front side of the cabinet frame** carefully measure the visual area of the width and the height that you can see through.



Once we have the measurements requested above we can then make a deduction for you so that the Leaded Glass Inserts will be smaller than the space allowed for glass. We will make a deduction of a total of 1/8" from the width and a total of 1/8" from the height of the **Tight Size Measurement** above. By making this deduction we will give you a 1/16" clearance on all four sides so that your glass inserts will fit perfectly and it tells us what size border lead works best for your cabinet frame. Making the glass slightly smaller than the maximum area allowed for glass. Call Dennis at 714 287-6447 if you have any questions, Thanks!